















(1)X1	(2)X1	(3)X1 (L)X1 (R)
		
BACK	SEAT	LARM LEFT ARM RARM RIGHT ARM
(4)X1	(5)X1	(6)X1
		
MECHANISM	GAS LIFT	BASE
(7)X5	(A)x4  M8*22 Mechanism Screw (B)x4  M8*45 ARM SCREW (C)x4  M6*30 L-Bar Screw (D)x4  ARM CAP (E)x1  ALLEN KEY (F)x1  ALLEN KEY	
	CASTERS	



Note: Please tighten all arm screws using allen key before step 6

Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using. This chair is only intended for sitting. Any other use will void the warranty.

